




Inspection for Corrosion Under Pipe Supports (CUPS)



Pipe Supports


- No direct access, perpendicular UT not applicable
- Medium and/or long range NDT techniques required to provide assurance
 - LRUT (GW)
 - SH-EMAT
 - CHIME
 - Multiskip




Long Range Guided Wave

- Low frequency Ultrasound (20-100kHz)
- Diameters 1.5" to 48" (up to 78")
- 100% Coverage
- Test Range - Typical $\pm 30\text{m}$
 - Depends on pipework geometry

Longitudinal



Torsional





Flexural






Long Range Guided Wave

- Amplitude response based on cross-sectional area of defect
- Prioritisation depends on amplitude and circumferential extent
- Screening technique – requires secondary NDT technique to quantify
- Prioritises pipe supports for follow-up actions




Medium Range Techniques

- Sonomatic have developed three techniques for the detection of degradation under pipe supports:
 - Shear horizontal electromagnetic acoustic transducers (SH-EMAT)
 - Creeping head wave inspection method (CHIME)
 - Multiskip




EMAT - Introduction

- EMATs are non-contact ultrasonic probes.
- The probe consists of a magnet and an electric coil.
- Suitable for samples with a thickness less than or equal to 15 mm.




EMAT - Dispersion curves


Lamb wave




SH wave



72 kHz lamb on 15mm pipe, 1 cycle CH1





340kHz SH on 15mm pipe CH1




EMAT - Probe setup

- Typically, probes are separated circumferentially and scanned axially over the pipe support.
 - Can also be used axially along pipe
- The signals produced cover the full circumference of the pipe
- Any degradation is indicated by a change in the signals.




EMAT – Example Results





CHIME - Introduction

- Transmitter fires pulse at critical angle – sets up regenerating creeping waves and head waves.
- A-scan at receiver shows a characteristic pattern that is a function of material thickness and profile between the probes.
- Suitable for samples with a thickness between 5 mm and 80 mm.



CHIME - Classification

- Type A – up to 10% of wall loss.
- Type B – between 10% and 40% of wall loss.
- Type C – greater than 40% of wall loss.





CHIME - Setups



Multiskip - Introduction

- Probes separation up to 2 m, NWT >10 mm, internal and external defects
- Different skip signals due to beam spread.
- Depth, location and extent of defects have different effect on arrival times of different skip signals




sonomatic®


Innovative Inspection Technologies

Multiskip - Inspection Capability

- Very accurate sizing of average thickness when there is no degradation (sizing typically better than 1 mm).
- Very accurate depth sizing of localised degradation (for example, sizing of a single pit typically to within 1 mm).




Copyright © Sonomatic Ltd 2018



Inspection Capability

Multiskip Sizing – current status

- Reasonable capability when degradation is very general, i.e. small variation in thickness across the support. An average thickness is obtained.



www.Sonomatic.com